


ANDYCINE

6" Touchscreen Camera Monitor

With F970 Power Kit



A6 Max

User Manual

Send Email to cs@andycine.com to receive the latest software updates and user information.

Overview

Thank you for choosing the Andycine A6 Max HDR Monitor.

Featuring a super high-resolution screen in a lightweight polycarbonate ABS chassis, and an array of essential production tools including waveform monitoring, vectorscope, luma, focus assist and F970 power kit to set up external wireless transmission.

This user manual will get you up to speed with all the amazing features packed into the A6 Max. Stay up-to-date with the latest information and software on www.andycine.com

Please read this manual carefully before you use.

Safety Instructions

The A6 Max is designed to a high standard but there are some things you should be aware of to prolong the life of the unit and for your own safety.

Using the A6 Max safely

Although the A6 Max is very lightweight compared to all the devices it replaces, it is still a solid object that could cause injury if misused.

- Always make sure that the A6 Max is mounted securely and is unable to fall onto anyone nearby. This is especially important when there are children present who might be tempted to pull on cables.
- Always ensure that cables that run to the A6 Max are clearly visible and do not present a trip hazard.
- Do not place on uneven or unstable surfaces.

- Do not touch the A6 Max screen with sharp, metallic or abrasive objects.
- Do not expose to strong electrical or magnetic fields.
- Do not expose to liquids, rain or moisture.
- Do not dispose of the A6 Max in municipal waste and do not incinerate it, always follow local regulations for safe disposal.

HDMI cables

Please remember that almost all HDMI cables do not use locking connectors and will simply pull out if they are jerked or tripped over.

Please ensure your cables make a secure connection and avoid flexing them excessively to maintain reliability.

What is included?

1 x A6 Max

1 x HDMI to Micro HDMI Cable

1 x Tilt Arm

1 x User Manual

1 x USB to USB-C Cable

Optional accessories including power and accessory kits and are also available. Visit www.andycine.com for the latest accessory options.

NP-F Battery

Carry Case

HDMI to HDMI Cable

HDMI to Mini HDMI Cable

DC 12V Power Adapter D-tap to 2pin DC Power Cable

Key Features

High-resolution 1920 x 1080 IPS Panel

High contrast of 1000:1

Bright 450 cd/m²

160° wide-view-angle IPS panel

Histogram/ 3D Lut

Focus assist (red, green, blue three colors optional highlight over parts of the image in focus)

Zebra/False color/Zebra exposure/Check field (red, green, blue, mono)

Embedded audio meter

Scan mode (underscan, overscan)

Zoom (4x, 9x, 16x)

Anamorphic mode (1.3x, 2x, 2x mag)

Pixel-to-pixel

Center marker

Safe area (80%, 85%, 90%, 93%, 96%, 2.35:1)

Ratio Marker (4:3, 13:9, 14:9, 15:9, 16:9, 1.85:1, 2.35:1)

Marker color (red, green, blue, white, black)

Image flip (H, V, H/V)

Image freeze


Color temperature adjustment

CONTENTS

1. Product Description	5
1.1 Front Panel Instruction	5
1.2 Rear Panel Instruction	5
1.3 Top Button Instruction	6
1.4 Bottom Port Instruction	6
1.5 Left Port Instruction	7
1.6 Powering the A6 Max	8
1.7 Sony NP-F970 Power Kit	8
1.8 Mounting Points	10
2. Menu Operation Instruction	12
2.1 Touch screen menu operation (default touch screen is on)	12
2.2 Button Menu Operation	13
3. Menu Function Instruction	14
4. How to Load 3D LUT?	19
5. Technical Parameters	21
6. Trouble Shooting	22
6.1 Only black and white or monochrome picture:	22
6.2 NO Image after put on the power	22
6.3 Earphone No sound	22


1. Product Description

1.1 Front Panel Instruction



Indicator Light: After connecting the power, the indicator light is on (red). Long Press  / TOUCH button to turn on the monitor, it turns yellow. After the signal is connected, it turns green.

1.2 Rear Panel Instruction




Battery Lock: The PUSH lock will lock after the battery installed, please press PUSH firstly before remove the battery.

NP-F Battery Slot: It is applicable to install NP-F series of batteries.


F970 Install and Power Kit: Installing the external equipment, like wireless transmitter, LED light, video converter and others which can be powered by Sony F970 battery. (The details see: **1.7 Sony F970 Install and Power Kit**)

1.3 Top Button Instruction



Button	Function when OSD is not displayed	Function when OSD is displayed
F1	Custom button F1	/
F2	Custom button F2	/
<	Decrease the volume or backlight	Decrease or adjust value of selected parameter
>	Increase the volume or backlight	Increase or adjust value of selected parameter
MENU	Display OSD Main menu	Return to previous OSD menu
∨	/	Select next menu item
∧	/	Select previous menu item
⏻	Power On/Off button	

1.4 Bottom Port Instruction




USB-C IN 5V: USB-C power input, polarity as the input power 

DC OUT 8.4V: DC power output, polarity as the output power 

Barrel output for powering your camera with a separately available DC coupler via adaptor (NP-FW50 Sony/LP-E6 Canon/DMW-BLF19 Panasonic/NP-FZ100/NP-W126S). More adapters coming soon.

 : 3.5mm earphone port output

1.5 Left Port Instruction



HDMI IN: HDMI signal input, up to 4K@30Hz, V1.4

HDMI OUT: HDMI signal output, up to 4K@30Hz, V1.4

DC IN 12V: DC power input, polarity as the input power 

1.6 Powering the A6 Max

(1) The rear cover of the monitor is equipped with a F970 battery plate, which is applicable to NP-F series of batteries.

Sony F970 battery plate for battery of Sony DV:

Sony F970 F960 F950 F930 F770 F750 F730 F570 F550 F530 series

Remark: It is recommended to use standard original F970 batteries.

Different specifications of the battery have different capability. The working time for the monitor will be different. Higher capability (working time) will be longer. Please take off the battery from the monitor if you don't use the monitor in a long time.

(2) **DC IN 12V:** DC power input, polarity as the input power , Barrel (5.5mm outer, 2.1mm inner) at the bottom of the monitor, DC 7~24V Input.


(3) **USB-C IN 5V:** USB-C power input, polarity as the input power . This port can be connected to the power bank for power supply and is not used for data transmission; it is recommended to be used only for local power supply, and it is not recommended to connect other devices to provide loop-out power.

1.7 Sony NP-F970 Power Kit

This HDMI monitor has an integrated dummy battery plate that allows you to mount and power optional accessories, such as wireless transmitters or receivers with an L-series battery slot.

The kit has two cross grooves, you can adjust the position of the external device by loosening 2 screws up and down / left or right, or install the kit upside down. When you don't need the kit, you can loosen the screws and remove the kit.

Note: Before disassembling the kit, make sure that the monitor is turned off, and then remove the battery or power adapter.




(1) Just move the kit: Loosen 2 screws, and then adjust up / down / left / right.

(2) Steps to remove the kit:

- ①. Loosen the 2 screws.
- ②. Use both hands to move the kit left.
- ③. Move the round holes to the corresponding 2 screws.

(You can also install the kit upside down.)



④. Then gently lift the kit upwards and carefully disassemble the 2P power cord.



⑤. Then remove the 2 screws.

(4) **Install back to the kit:** first screw the 2 screws back to the screw hole used to install the kit on the back of the monitor, install the 2P power cable to the cutout, then align the round hole of the kit with the screw, and then push the kit to the screw at the center of the kit cross, then tighten the screws.

1.8 Mounting Points


(1) 1/4-20 Thread Points

There are (4) 1/4-20 thread points (top, bottom, right side & Back center) can be mounted easily to the hot shoe mount or magic arm etc.



(2) Tilt Arm Mounting

The monitor secures to your camera using the included Tilt Arm via shoe mount or 1/4"-20 thread. The Tilt Arm enables 180° of tilt for convenient monitoring at nearly any angle. A cold shoe on the Tilt Arm lets you secure equipment (like a microphone, LED light, or wireless receiver) that would otherwise be displaced from the camera's accessory shoe.



2. Menu Operation Instruction

After the monitor is properly connected to the power supply, the indicator light is on (red). Long press **⏻ / TOUCH** button to turn on the monitor, the indicator light turns yellow. After the signal is connected, the indicator light turns green.


After startup, short press **⏻ / TOUCH** to select to turn the screen touch function on or off.

2.1 Touch screen menu operation (default touch screen is on)

- ①. Double-click on the screen to open the main menu (on the left side of the screen) and click on the corresponding menu to display the secondary menu.

- ②. Swipe up from the bottom of the screen to open the shortcut menu and click on the corresponding menu to open or set the corresponding function.
- ③. On the left side of the screen (1/2 split screen), you can directly adjust the brightness of the screen backlight; on the right side of the screen (1/2 split screen), you can directly adjust the volume.

Figure:



2.2 Button Menu Operation

- (1) When the menu is not displayed, directly press the "<" or ">" button to adjust the volume or backlight. You can set the left and right buttons in the menu  Left Right Key Set to set the volume or backlight.
- (2) Short press the MENU button to open the main menu (on the left side of the screen). Press "∨" or "∧" to select the secondary menu, press ">" to enter the secondary menu, and then press "∨" or "∧" to select the secondary menu Menu options. After selecting the secondary menu option, press "<" or ">" to adjust the parameter value. After adjusting to the preset parameters, press the "∨" or

"^" button to enter the next adjustment. After adjustment, press "MENU" to exit.

- (3) After booting, you can choose to turn on or off the screen touch function in the Touch Switch in the  (the touch screen is turned on by default). In the closed state, you need to select the Touch Switch option according to the ② step of the Button Menu Operation, and then press the "<" or ">" button to turn on the touch function.

3. Menu Function Instruction



All Waves	Off, On After turning on, waveform, vector, histogram and embedded audio will be shown.
Waveform	Off, RGB, Y, YUV This essential feature assists with the calibration of professional video cameras. It shows the overall brightness of the image assisting the video professional in correcting exposure. The waveform feature also checks the evenness of the lighting when lighting a chromakey or background.
Vector	Off, On shows how saturated the image is and where the pixels in the image land on the color spectrum.
Histogram	Off, RGB1, Y, RGB2

Waves Trans.	Off, 25, 50, 75
Focus Assist	Off, On By sharpening the edge of images to help photography for focusing operation.
Peaking Color	Red, Green, Blue Due to the image color is colorful when shooting in natural light, so the user may react to the edge of the single line not too sensitive, at this time to change the auxiliary focal edge line color will improve the sensitivity of the image contour. It is convenient during filming tracking in focus. The edge line color can be chosen according to the site situation to select red, green and blue.
Embedded Audio	Off, On The Audio Level Meters provide numerical indicators and headroom levels. The audio meter is green, and will turn yellow when exceeds -20dB, and turn red when exceeds -9dB.



Nine Grid	Off, On
Safe Frames	Off, 80%, 85%, 90%, 93%, 96%, 2.35:1 To select the screen marker.
Center Marker	Off, On
Ratio Marker	Off, 4:3, 13:9, 14:9, 15:9, 16:9, 1.85:1, 2.35:1 Image display ratio marker.
Mark Color	Red, Green, Blue, Black, White To select the above high contrast mark color according to different image.
Mark Width	1~7

	To select the above mark color display width.
Modified Mark	0~5 Adjust the brightness of the image outside tag line to highlight the inside tag line of image.



Scan Mode	Under Scan, Over Scan
Aspect Ratio	Auto., 4:3, 16:9, Just Scan, Panorama, P2P
Anamorphic	Off, 1.3X, 2.0X, 2.0X MAG, User Under the User , the Anamorphic nX can be customized.
Anamorphic nX	1.20X~2.00X
Image Flip	Off, H Flip, V Flip, H_V Flip
OSD Flip	Off, On
Zoom Mode	Off, Mode1, Mode2 The Zoom All can be customized.
Zoom All	0~500
Nine Grid Zoom	Off, On Open the Nine Grid function in the  to divide the image into nine grid, then turn on the Nine Grid Zoom function, select one of the screens by pressing the "<" or ">" key, and then press the "V" or "^" key zoom in to full screen. Press the "V" or "^" key to exit the local zoom function. (To achieve this function, you need to turn on the Nine Grid function first, and it can only be operated by keys.)
Zoom	Off, 4X, 9X, 16X
Image Freeze	Off, On



Lut Switch	OFF, ON After the LUT Switch is turned on, you can use the Lut (SLOG2, SLOG3, LOGC, VLOG) .
Lut Table	Show the 4 built-in Lut and the custom load Lut
Lut Import (USB-C)	After copying the 3D LUT file to the U disk and inserting it into the TYPE-C to USB Connector, you can click the “<” or “>” key in the Lut Import(USB-C) to import the 3D LUT file.
Color Temp.	5600, 6500, 9300, User Under the User , the red, green and blue of the image can be adjusted.
Red	0~255
Green	0~255
Blue	0~255
Backlight	0~100
Pic. Mode	Standard, Mild, User, Dynamic Under the User , you can adjust the image Brightness, Contrast, Saturation, and Sharpness .
Brightness	0~100
Contrast	10~100
Saturation	0~100
Sharpness	0~100
Tint	0~100



Left Right Key Set	Volume, Backlight You can set the Left Right Key Set as shortcut keys for volume or backlight adjustment. After setting, when the menu is not
---------------------------	--

	displayed, you can directly press the "<" or ">" key for quick adjustment.
Language	English, 简体中文, Español, Português, Français, Nederlands, Deutsch, 日本語, 繁體中文
OSD Trans.	Off, Low, Middle, High
OSD Time	Off, 10Sec, 20Sec, 30Sec
No Signal	Blue Screen, Red Screen, Green Screen, Gray Screen, Black Screen, White Screen
Volume	0~100
Touch Switch	On, Off When the touch screen is closed, you need to select the Touch Switch option according to step ② of the Button Menu Operation , and then press the "<" or ">" key to turn on the touch function.
USB Upgrade	Copy the file to the U disk, insert the Type-C to USB female adapter, and then connect to the Type-C interface of the monitor, press the ">" button to confirm the upgrade. After the upgrade is complete, the monitor will automatically restart.
Reset	Press “>” button to confirm, back to original setting.



F1/F2	Safe Frames, Check Field, Focus Assist, Aspect Ratio, Image Flip, Image Freeze, Histogram, False Colors, Over Exposure, Embedded Audio, Nine Grid, Zoom, Anamorphic, Waveform, Vector, Center Marker To set the 2 shortcut custom button F1, F2 on the panel. e.g. Tap the menu “  ”, select F1 , then tap “<” or “>” to
--------------	--

	pop-up function items to select one of them, such as “Focus Assist”. So when you exit menu, you could press F1 directly on the front of panel to turn on “Focus Assist” function. Same setting for F2
--	---

4. How to Load 3D LUT?

1. SD Card Format FAT32 and NTFS
2. Max Files Limit Maximum 50 Lut files
3. File Requirements The lut should in.cube Single file not exceeded to 7.9Mb Support LUT-3D-Size 16,17,32,33,64,65 The files should be valid The files' name should in English or Arabic Words

4. Steps and Instruction Make sure that the SD card correctly insert
Enter the Monitor Menu---“Color”---“Load Lut”

After this, the monitor will auto detect the sd card

A. There is no SD Card The screen will show failed,can try one more time,if not work, restart the monitor

B. There is SD Card The monitor will erase the exits user's lut fill and show “Initializing” If there is no valid lut file in sd card, the lut will not load.The monitor will show “clean up”

C. If there is valid lut file in sd card, the monitor will load lut files and show “[n] name. The [n] shows the quantity number. The “name” should in lut files' name. If load successful, the screen will show “complete[n]”.
[n] Stands for the quantity number for lut files should under 50.

Firmware Updates (AndyOS)

From time to time we will issue software updates for your Andycine Monitor. To update the firmware (that's the software that runs inside your Andycine Monitor), there is a simple procedure you have to follow.

1. Extract the files .bin from the firmware zip file.
2. Copy these files onto a SD Card.
 - a. AndyOS recommends you use a freshly formatted compatible SD Card (FAT32 or NTFS).
 - b. Ensure that the firmware update file is on the root of the SD card, and not in a folder or sub folder.
3. Insert the SD Card with A6 Max.bin file.
4. Use a freshly charged battery on your A6 Max or connect to mains power. It is very important that your monitor does not lose power during a firmware upgrade.
5. Power up your monitor with a long press of the Power Button.
6. Double tap monitor screen to access menu, Select Setting, Select firmware to update.
7. Watch the screen, the firmware upgrade will start.
8. While the firmware upgrade is happening, an 'updating firmware' screen will appear.
9. The firmware upgrade will take up to a few minutes.

Let it finish updating when finish it should reboot, if not, turn it off and on again

Done

5. Technical Parameters

Panel Size	6" touch screen
Resolution	1920 x 1080 pixels
Dot Pitch	0.069(H) x 0.069(V) (mm)
Aspect Ratio	16:9
Brightness	450cd/m ²
Contrast	1000:1
Viewing Angle	80°/80°(L/R) 80°/80°(U/D)
Backlight	LED
Input	HDMI V1.4
Output	HDMI V1.4
HDMI Input/Output Support Format	480i/576i/480p/576p 720p (60/59.94/50/30/29.97/25/24/23.98) 1080i (60/59.94/50) 1080p (60/59.94/50/30/29.97/25/24/23.98) 3840×2160p (30/29.97/25/24/23.98) 4096×2160p (24Hz)
Audio	3.5mm stereo headphone jack
Power In	DC IN 12V, Barrel (5.5mm outer, 2.1mm inner) USB-C IN 5V Note: please use 5V/2A or more than 2A USB-C power
Power Out	DC OUT 8.4V, Barrel (5.5mm outer, 2.1mm inner; Power DSLR or mirror-less camera)
Input Voltage	7~24V, Barrel (5.5mm outer, 2.1mm inner)
Power Consumption	≦ 8W
Unit Size	148Lx93Hx21.75D (mm)
Unit Weight	245g (with F970 power kit)
Mount Points	(4) ¼-20 thread points (top, right, bottom&back center)
Working Temperature	-20℃~50℃
Storage Temperature	-30℃~60℃

6. Trouble Shooting

6.1 Only black and white or monochrome picture:

- ① please check saturation, brightness & contrast adjustment.
- ② Please check "Monochrome" is in black, white or monochrome image or other condition.

6.2 NO Image after put on the power

- ① Check if signal cable connecting is in good condition.
- ② Check signal cable connecting, and make sure to use the standard adapter to connect the monitor. If power is supplied by battery, please check if the battery is fully charged.

6.3 Earphone No sound

Check if Volume control do not open, press the volume button, and try to increase the volume.

If you have more questions, please contact us

Customer Support: **cs@andycine.com**

Sales Inquiry: **sales@andycine.com**

Website: **www.andycine.com**

Facebook/Youtube: **@andycinegear**

Instagram: **@andycinegear**

Twitter: **@andycinegear**

★ Please note: Specifications are subject to change without notice. All information correct at time of publishing.