IMPORTANT SAFETY INSTRUCTIONS:

- Please read user guide before using this product.
- Please keep user guide for future reference.
- Please read the cautions to prevent possible danger and loss of property.

FEATURES:

- High resolution: 1920×1200;
- Wide voltage: DC 7-24V;
- High brightness: 500cd/㎡;
- High contrast: 1000:1;

CAUTIONS:

1. Please do not place the display screen towards the ground.
2. Please avoid heavy impact or drop onto the ground.
3. Please do not use chemical solutions to clean this product. Please wipe with a clean soft cloth to maintain the brightness of the surface.
4. Please do not block any vent hole.
5. Please follow the instructions and trouble-shootings to adjust the product. Other improper adjustment may result in damage. Any further adjustment must be performed or conducted by a qualified technician.
6. Please unplug the power and remove the battery if long-term no-use,

or thunder weather.

YP-01180328-1

Contents

1. PRODUCT DESCRIPTION 4

2. DV BATTERY MOUNT PLATE 5

3. MENU SETTING..... 6

4. ACCESSORIES 9

5. PARAMETERS 11

6. TROUBLE SHOOTING 11

HDMI®2
HIGH-DEFINITION MULTIMEDIA INTERFACE

Confirm function: press to confirm after option selected.

3．EXIT

4． F1、F2、User-definable buttons.

Default functions:（function customized to meet your needs）

F1 Peaking F2 Level Meter

5． INPUT: circularly switch among of SDI and HDMI.

6. Cooling holes

7． Speaker

8． SDI input interface.

9． SDI output interface.

10． Earphone jack.

11． USB input

(Only for program upgrades, do NOT use if non-professionals)

12． HDMI output interface.

13． HDMI input interface.

14． DC 12V power input.

2. DV BATTERY MOUNT PLATE

Standard mounts process



DV Battery Mount Plate Specification:

F970 for battery of SONY DV: DCR-TRV series, DCR-TRV E series, VX2100E PD P series, GV-A700, GV-D800 FD/CCD-SC/TR3/FX1E/HVR-AIC, HDR-FX1000E, HVR-Z1C, HVR-V1C, FX7E F330.

3. MENU SETTING

Before setting the functions, please make sure the device is connected correctly.

3-1. F1~F2 User-definable function buttons:

Select "MEMU -- SYSTEM -- F1 Configuration/F2 Configuration" to custom F1 / F2 shortcut settings. Then left or right sliding the dial to choose options.

Select option via sliding to the left or right.

Press to confirm option as default, then press EXIT to exit.

Functions of F1-F2 buttons can also be customized: Center Marker, Aspect Marker, Check Filed, Underscan, Scan, Aspect, DSLR, Freeze, Peaking, False Color, Exposure, Histogram, Level Meter.

F1-F2：2 user-definable function buttons

Default function:

F1：Peaking F2：Level Meter

	Peaking Color	Red, Green, Blue, White, Black
	Peaking Level	0~100
	False Color	OFF, ON
	Exposure	OFF, ON
	Exposure Level	0~100
	Histogram	OFF, ON
Audio	Volume	0~100
	SDI Audio Channel	Ch0&Ch1, Ch2&Ch3, Ch4&Ch5, Ch6&Ch7, Ch8&Ch9, ChH10&Ch11, Ch12&Ch13, Ch14&Ch15**(available under SDI mode only.)**
	Level Meter	OFF, ON
System	Language	English, Chinese
	OSD Timer	10s, 20s, 30s
	Image Flip	OFF, H, V, H/V
	Back Light	0~100
	F1 Configuration	Peaking
	F2 Configuration	Level Meter
	Reset	Press to confirm after selected.

4. ACCESSORIES

Standard:



1. 12V DC adapter 1 piece
2. HDMI A/C cable 1 piece
3. Shoe mount 1 piece
4. Folding sun shade cover 1 piece
5. VESA battery plate 1 piece
6. Manual 1 copy

Panel	7” IPS
Physical Resolution	1920×1200 (324ppi)
Brightness	500 cd/㎡
Contrast	1000: 1
Viewing Angle	170°/ 170°(H/V)
Input Voltage	DC 7-24V
Input Signal	HDMI, SDI
Output Signal	HDMI, SDI
4K HDMI	4096×2160 24p / 3840×2160 (23/24/25/29/30p)
Power Consumption	≤12W
Operating Temperature	-20℃~60℃
Storage Temperature	-30℃~70℃
Dimension (LWD)	182×124×22mm
Weight	435g

5. PARAMETERS

6. TROUBLE SHOOTING

1. Only black-and-white display:

Check whether the color saturation is properly setup or not.

2. Power on but no pictures:

Check whether the cables of HDMI are correctly connected or not. Please

use the standard battery.

3. Wrong or abnormal colors:

Check whether the cables are correctly and properly connected or not. Broken or loose pins of the cables may cause a bad connection.

4. When on the picture shows size error:

Press “MENU → FUNCTION → Underscan” to zoom in/out pictures automatically when receiving HDMI signals

5. Other problems:

Please press dial button and choose “MENU→SYSTEM→ Reset →ON”

Note: due to constant effort to improve products and product features, specifications may change without notice.