


Thank you for choosing Bolt


One-year limited warranty

Congratulations on the purchase of your Bolt Beauty Dish and Grid Kit for the VB-Series Bare-Bulb Flashes. Included in this kit is a 12" diameter beauty dish for creating a soft, yet crisp, quality of light; a 40° snap-in grid for increased contrast and directionality; and a diffuser sock for softening light output. **To install the grid and/or diffuser sock, please follow these steps:**


Remove the reflector if installed on the flash.



Install and secure the beauty dish to the accessory mount.



Snap the grid into the mouth of the beauty dish. To use the diffuser sock, stretch the elastic rim over the edge of the beauty dish.



Note: The diffuser sock can be used with or without the grid in place.