



Ronin 4D Raw License Activation Method

Steps

1. Connect Ronin 4D to a computer via the cable included in the Ronin 4D package.
2. Power on Ronin 4D.
3. Launch DJI Assistant 2 (Ronin Series), and log in with the DJI account that purchased the activation key.
4. Click the Ronin 4D icon in DJI Assistant 2, and enter the parameter settings page.
5. Click "License" on the left.
6. Enter the verification code sent to your email/phone number used at the time of purchase.
7. Click "Confirm".
8. Then, click "Continue Activation" in the next window.
9. DJI Assistant 2 will show the activation progress.
10. DJI Assistant 2 will then show that the activation is successful.