

# WEBCAM

C925e

Setup guide | Guide d'installation



logitech®

## CONTENTS

|                    |   |                     |   |
|--------------------|---|---------------------|---|
| English . . . . .  | 3 | Español. . . . .    | 7 |
| Français . . . . . | 5 | Português . . . . . | 9 |

**[www.logitech.com/support/c925e](http://www.logitech.com/support/c925e)**


## Thank you for buying your Logitech Webcam C925e!

Use this guide to set up your Logitech webcam and to begin making video calls.

For questions or technical support, please visit [www.logitech.com/support/c925e](http://www.logitech.com/support/c925e).

### FEATURES

1. Autofocus HD 1080p lens
2. Omni directional microphones
3. Activity light
4. Flexible clip/base
5. Privacy shutter
6. Tripod attachment



## SETTING UP YOUR WEBCAM


### 1. Place your webcam

Designed for the way you like to make a video call, place the webcam where you want it—on a computer monitor, desktop, or tripod.


#### For placement on a monitor:

Grasp the webcam as shown and open the flexible clip/base with your other hand. Mount the webcam, making sure the foot on the flexible clip/base is flush with the back of your monitor.

1



2



### 2. Connect the webcam

Connect the webcam to a computer USB port. The Windows® UVC or Mac drivers are loaded automatically. Driver installation may take a few moments.

### 3. Use the webcam

The webcam does not ship with video calling software. To make a video call, use your video calling application.

[www.logitech.com/support/c925e](http://www.logitech.com/support/c925e)