



ES-WM Outdoor Wall Mount

Installation Guide





What's in the box


	Outdoor Wall Mount ES-WM x1
	Mounting Support Bracket x1
	Positioning Template x1


	Screw (1/4 -20UNC) x4
	Safety Cable x1


Wall Mount Dimensions














NOTE: All measurements are specified in millimeters.

Orientation Installation Guide for EX-Ultra Series Cameras


Upright Position	Upside Down Position
	

Step-by-step guide for installing the outdoor wall mount:

Step 1: Position the template where the installation is required. Utilize a power drill to create holes precisely at the marked locations.




Step 2: Align the support bracket with the drilled holes. Insert the screws through the holes in the bracket and into drilled holes. Tighten the screws until the bracket is securely attached to the wall.




Step 3:


1. Connect the Mounting Support Bracket and ES-WM with the Safety Cable.
2. Thread cables through the ES-WM’s bottom hole.
3. Align all screws with the ES-WM’s holes.
4. Apply downward pressure to firmly secure the Mounting Support Bracket and ES-WM together.




Step 4: Fasten the bracket in place using nuts.




Step 5: Secure the camera by tightening four screws onto its bottom.




Step 6: Fasten the camera to the ES-WM utilizing the Safety Cable.




Step 7: Match the camera's triangle with the ES-WM's EX./EXU Series Sign.




Step 8: Tighten the screw.




Step 9: Thread the cables through the waterproof case.




Step 10: Plug cables into the camera’s ports.



Step 11: Attach the waterproof case and secure it by tightening the four screws.



Step 12: Align the cover’s holes with the ES-WM’s



Step 13: Secure the M3 x 4 tightly.

