impact®



BP-RA-MBH

Right Angle Baby Plate

with Mini Ball Head

INSTRUCTIONS

Introduction

Thank you for choosing Impact.

The BP-RA-MBH Right Angle Baby Plate securely mounts a camera or camcorder onto a wall. Its 8-inch baby pin can support a camera and lens combination that weigh up to 6 pounds, and the included mini ballhead lets you precisely adjust the camera's angle and the distance from the wall. The metal mounting block and ballhead are removable for camera swapping or maintenance, and they can be mounted on any tripod, light stand, or C-stand with a 5/8-inch stud. The plate mounts with four screws or other wall fasteners.

Precautions ⚠⚡

- Securely mount the plate to the wall before use.
- Make sure that this product is intact and that there are no missing parts.
- Do not exceed the maximum load capacity.
- All images are for illustrative purposes only.

Specifications

Plate Dimensions	3.2 × 5.9 in. (8 × 15 cm)
Arm Length	8 in. (20.3 cm)
Load Capacity	6 lb. (2.7 kg)
Weight	1.5 lb. (689 g)
Screw Size	1/4 in.
Pin Diameter	5/8" (16mm)

Overview


1. Screw holes
2. Ballhead locking knob
3. 1/4-20 mounting bolt
4. Mini ballhead
5. Baby pin
6. 5/8 in. receiver
7. Mounting block
8. Mounting block locking knob
9. Wall plate

You'll Also Need

- Wall fasteners (anchors and screws, molly bolts, or toggle bolts)
- Drill bit (see the fastener's packaging for appropriate size)



Installation Instructions




1. Use the wall plate to mark the position of the mounting holes on the wall.

2. Drill holes in the marked locations. Make appropriately sized holes for the wall anchors, molly bolts, or toggle bolts. If you're using wall anchors, tap the anchors into the holes.

   Note: Many wall anchors and molly bolts are self-tapping and don't require a drill for installation.

3. Put the plate against the wall, and insert screws (for wall anchors), molly bolts, or toggle bolts through the holes, and fasten them until they're fully tightened, and the the plate is secure.

   Note: When screwing the plate directly into a wall stud, make sure at least two screws are attached to the stud.



4. Slide the mounting block onto the baby pin, and tighten the locking knob until secure. You can attach the mounting block horizontally or vertically, via the 5/8-inch receivers on the sides (4a) or the bottom (4b) of the block.

5. Make sure the ballhead's locking knob is tightened, and screw the camera onto the ballhead's 1/4-20 bolt.

6. Use the ballhead's locking knob to adjust your camera's position and angle.

Important! Do not exceed the ballhead's 6-pound weight capacity. For larger cameras and lenses, use a mini ballhead with a greater weight capacity, like Oben's MBH-11 ballhead.

Remove the mounting block and ballhead from the wall plate to use it with any tripod, light stand, boom arm, or C-stand that has a baby pin.

Once the mounting block is removed, the 8-inch baby pin can mount a light fixture or accessory with a 5/8-inch receiver to a wall. Make sure the fixture or accessory doesn't exceed the weight capacity of your wall fasteners.


4a


4b


5


6

One-Year Limited Warranty

This Impact product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Impact Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Impact along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.impactstudiolighting.com or call Customer Service at 212-594-2353.

Product warranty provided by the Gradus Group.

www.gradusgroup.com

Impact is a registered trademark of the Gradus Group.
© 2020 Gradus Group LLC. All Rights Reserved.

IMPACT®
A Gradus Group Brand