OPERATING THE RBF-20-V2 CONTROL BOX

CCT MODE

Use this mode to set the LEDs' color temperature.

- Press the Mode button so CCT blinks on-screen, and press the Confirm button.
- Use the Color knob to adjust the color temperature from 2750 K to 6500 K in 100 K increments.
- Use the Brightness knob to adjust the brightness from 10% to 100% in 5% increments.

SPECIAL MODE

Use this mode to select between seven preprogrammed special effects.

1. Press the Mode button so Special blinks on-screen, and press the Confirm button to select it. The effect will immediately begin to play.
2. Use the Color/Mode knob to scroll through the seven preprogrammed effects. When the desired effect blinks on-screen, press the Confirm button to select it.
3. To change the effect, turn the Color/Mode knob until the desired effect blinks on-screen, and press the Confirm button. The new effect will start playing.

EDITING THE EFFECTS

Brightness or speed settings can be adjusted in each mode by turning the Brightness knob.

- SOS, Watch TV, Lightning, and Photo have adjustable brightness in 10% increments.
- Heart, Cycle, and Flash have adjustable speed. Changing the speed increases or decreases the interval between events. CCT mode determines the color temperature of these effects.