
GABOR



FM-N / FIXED
MOUNT

for Extra-Small Flat-Panel Displays

User Manual

Thank you for choosing Gabor.

This Gabor Fixed Wall Mount offers a durable and discreet attachment for wall-mounted TVs and monitors. It accommodates flat-panel displays with screen sizes measuring 10 to 30 inches and allows them to hang a mere half inch from the wall. The sturdy steel construction supports a maximum weight of 55 pounds, and with the simple installation, you'll be viewing your display in just a few steps.

If you have safety concerns about installing this product, contact a qualified professional or installation contractor.
If this product is missing hardware or there are defective parts, visit www.madebygabor.com or call Customer Service at 212-594-2353.

Safety Warnings

- When installing this product, be sure to refer to the mounting instructions detailed in this manual; failure to abide by the mounting instructions may void the product's warranty.

- Do not use this product for any flat-panel display other than what it is intended for; the exact specifications, size parameters, and weight limits are found both on the product box and in the instruction manual.

- It is strongly recommended that this product be installed by a qualified professional or installation contractor; Gabor takes no responsibility for any product damage or personal injury resulting from mishandling, incorrect mounting, faulty assembly, or improper use of this product.

- This product has been designed specifically for mounting directly on wooden studs or concrete walls; depending on wall type and material, the use of additional appropriate mounting hardware and/or accessories such as heavy-duty anchors may be required.

- This product may contain small parts which can possibly pose a choking hazard; keep out of reach of children and pets.

- Do not mount the device on structures that may be affected by vibrations or noticeable impacts; do not install near a heater, fireplace, or any other source of direct heat energy.

- The supplied mounting hardware is not intended for use on metal studs or cinder block walls, and may not be appropriate for old or weak walls; it is best to consult with a qualified professional to determine whether your wall is capable of supporting this bracket.

- It is recommended that at least 2 people perform the installation process to prevent injury from mishandling or dropping the product and/or flat-screen device.

- Excessive exposure to liquids may damage the finish of this product; when cleaning this product, use only a mild detergent solution, and quickly wipe dry with a soft cloth.

- All images are for illustrative purposes only.

Product Specifications

Depth from Mounting Source
0.51 in. (13 mm)

Material
Steel

Recommended Screen Sizes
10 to 30 in. (25.4 to 76.2 cm)

Weight
4.76 lb. (2.16 kg)

VESA Mounting Patterns
75×75 mm
100×100 mm

Max Weight Capacity
55 lb. (25 kg)



Overview

Display mounting plate




Wall bracket



A **4X**  M4 × 14 mm screws	**B** **4X**  M5 × 14 mm screws
C **4X**  D5 washers	**D** **2X**  Anchor screws
E **2X**  Concrete anchors	**F** **2X**  Anchor screw washers
G **1X**  Wall bracket template	**H** **1X**  Bubble level

Required Tools

Drill




Phillips screwdriver



Hammer



Stud finder



Tape measure



3/16 in. (4.5 mm) Wood drill bit



3/8 in. (10 mm) Concrete drill bit



Pencil



Display/TV Placement


Before installing the Gabor Fixed Wall Mount, you will need to determine the placement of your display and identify surrounding support structures for attachment.

The best height for a display is at the viewer's eye level. You can find this height in one of two ways.


1. Measure the distance from the seating area to the viewing area. The ideal position is when the center of the display (where the diagonals meet) is as close as possible to eye level.

OR


2. Cut a piece of sturdy cardboard that's approximately the same size as your display. Use the cardboard to find a comfortable height, and mark the mounting location with a pencil.




Remove the Display Mounting Plate



Loosen the security screw, and remove the plate from the wall bracket.




Attaching the Display Mounting Plate




Selecting the Right VESA Mounting Hardware for Your Display

A variety of screws are included to fit VESA standards on the backs of most displays. Select the M4 or M5 screws that best fit your display. Hand-thread the screws to determine the correct diameter.

Install the mounting plate directly to your display.







If the screw is too short, it may not hold the display. If it's too long, it may damage the display.


Attaching the Wall Bracket to Wooden Studs

Wooden studs run vertically inside the wall, 16 inches apart, behind the drywall or plaster. The wall bracket must be mounted to a wooden stud, or the bracket could fall out and damage your display or cause personal harm.




1. Use a stud finder to locate the edges of the wooden stud, and mark the center.






2. Place the wall bracket template up to the marked locations, and tape it to the wall. Use the included bubble level to make sure the template is level before drilling. Use a pencil to mark the two drilling holes for the anchor screws, and then apply a piece of tape over the marks.

Attaching the Wall Bracket to Wooden Studs (cont.)







3. Use a 3/16-inch (4.5 mm) wood drill bit to predrill the marked spots 2.2 inches (55 mm) deep, and then clean out the debris from the holes. Remove the template from the wall.

4. Attach the bracket to the wall by inserting the two anchor screws through the washers and the wall bracket's mounting holes, and screw them into the predrilled support holes until secure. Do not overtighten the screws.

Attaching the Wall Bracket to Concrete




Warning! Make sure the concrete wall is solid and at least 8 inches (20 cm) thick. If the concrete exhibits cracks or other defects, this may result in failure of the concrete anchors and cause serious personal injury or damage to your display.




1. Place the wall bracket template up to the marked locations, and tape it to the wall. Use the provided bubble level to make sure the template is level before drilling. Use a pencil to mark the two locations as shown, and place a piece of tape over each mark.

Attaching the Wall Bracket to Concrete (cont.)

2. Use a 3/8-inch (10 mm) concrete drill bit to predrill the marked spots 2.4 inches (60 mm) deep, and then clean out the debris from the holes.





3. Remove the template and Insert the concrete anchors into the predrilled holes, and use a hammer to tap the anchors into the concrete.



4. Attach the bracket to the wall by inserting the anchor screws through the washers and the wall bracket's mounting holes, and screw them into the anchors until secure. Do not overtighten the screws.


Mounting the Display on the Wall Bracket






Important! We recommend that two people perform this step.

1. Lift your display up to the wall bracket, and seat the display mounting plate's flanges into the wall bracket's flanges.



Mounting the Display on the Wall Bracket (cont.)

2. Replace the security screw, and screw it in until secure.



Five-Year Limited Warranty

This Gabor product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of five (5) years from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Gabor Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Gabor along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.madebygabor.com or call Customer Service at 212-594-2353.

Product warranty provided by the Gradus Group.

www.gradusgroup.com

Gabor is a registered trademark of the Gradus Group.

© 2020 Gradus Group LLC. All Rights Reserved.

GABOR®
A **Gradus Group** Brand

GG1

www.MADEBYGABOR.com