Magnetic Plates



Nonadhesive Square Plate

Place inside your device's case, with the felt side facing your device.



Round Adhesive Plate

Apply the clear protective sticker to the back of your phone or case. Then apply the round plate over the protective tape.

Tilt Lock

Twist the locking ring counterclockwise to loosen, and clockwise to tighten.

***Important!** Always support the device with one hand when loosening the lock.*

