Thank you for choosing Magnus.

The Magnus VR-SO Pan-Handle Video Remote attaches select Magnus tripods to select Sony camcorders and cameras to provide remote access to video and photo functions. It offers a remote handle for your tripod, allowing you to manually pan and tilt your tripod-mounted camera with hands-on access to functions such as telephoto and wide-angle zoom, start and stop video, and shoot single, continuous, and long-exposure photos.

User Cautions

- Please read and follow these instructions, and keep this manual in a safe place.
- Keep this unit away from water and any flammable gases or liquids.
- Clean the unit with a soft, dry cloth.
- Keep this unit away from children.
- Make sure this item is intact and that there are no missing parts.
- Features vary by model.
- All images are for illustrative purposes only.

www.magnustripods.com

ONE-YEAR LIMITED WARRANTY

This MAGNUS product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function. This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state. To obtain warranty coverage, contact the Magnus Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Magnus along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense. For more information or to arrange service, visit www.magnustripods.com or call Customer Service at 212-594-2353.

MAGNUS® A Gradus Group Brand

Product warranty provided by the Gradus Group.
www.gradusgroup.com
Magnus is a registered trademark of the Gradus Group.
© 2021 Gradus Group LLC. All rights reserved.

GG1

MAGNUS®



VR-SO

Owner's Manual

MAGNUS®

Pan-Handle Video Remote for Select Sony Cameras

Overview







1. Mini-USB port
2. Strap hole
3. **Power/Rec LED:**
   Green: Remote is receiving power
   Red: Recording
   Flashing red: Camera battery is low
4. **Sleep button:** Press to enable the camera's sleep mode. Press again to wake the camera.
5. **Grid Line button:** Enables your camera's grid line feature.
6. **Photo/Lock:** Press to take a single photo. In continuous mode, slide to Lock to take continuous shots. In Bulb mode, slide to Lock to take long exposures.
7. **Record/Stop:** Start and stop video recording.
8. **T/W zoom rocker switch:** Zoom from wide angle to telephoto. The zoom speed changes based on the position the rocker switch. The harder or farther you press, the faster it zooms.
9. **Push Release button:** Releases the remote from the pan arm.
10. **Slow Zoom switch:** Slows the zoom speed when engaging the T/W zoom rocker switch.
    Note: The Slow Zoom speed varies depending on the camera.
11. Pan arm
12. Thumbscrew
13. Remote USB cable
14. Multi Terminal connector
15. Mini-USB connector

Also Included:

Lanyard

Attaching the Pan Arm



Specifications

Camera connector: Multi Terminal
Remote connector: USB Mini-B
Power source: Camera
Cable length: 31.5 in. (80 cm)
Weight: 3.2 oz. (91.8 g) remote only
Dimensions with handle (H × W × D): 1.4 × 1.5 × 11 in. (3.5 × 3.9 × 28 cm)