INSTRUCTION MANUAL

SB-6531T/SB-6531R

HDMI to Fiber Optic Extender



SHINYBOWUSA

MULTIMEDIA AUDIO AND VISUAL

SAFETY INFORMATION

1. To ensure the best results from this product, please read this manual and all other documentation before operating your equipment. Retain all documentation for future reference.
2. Follow all instructions printed on unit chassis for proper operation.
3. To reduce the risk of fire, do not spill water or other liquids into or on the unit, or operate the unit while standing in liquid.
4. Make sure power outlets conform to the power requirements listed on the back of the unit. Keep unit protected from rain, water and excessive moisture.
5. Do not attempt to clean the unit with chemical solvents or aerosol cleaners, as this may damage the unit. Dust with a clean dry cloth.
6. Do not use the unit if the electrical power cord is frayed or broken. The power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords and plugs, convenience receptacles, and the point where they exit from the appliance.
7. Do not force switched or external connections in any way. They should all connect easily, without needing to be forced.
8. Always operate the unit with the AC ground wire connected to the electrical system ground. Precautions should be taken so that the means of grounding of a piece of equipment is not defeated.
9. AC voltage must be correct and the same as that printed on the rear of the unit. Damage caused by connection to improper AC voltage is not covered by any warranty.
10. Turn power off and disconnect unit from AC current before making connections.
11. Never hold a power switch in the “ON” position.
12. This unit should be installed in a cool dry place, away from sources of excessive heat, vibration, dust, moisture and cold. Do not use the unit near stoves, heat registers, radiators, or other heat producing devices.
13. Do not block fan intake or exhaust ports. Do not operate equipment on a surface or in an environment which may impede the normal flow of air around the unit, such as a bed, rug, carpet, or completely enclosed rack. If the unit is used in an extremely dusty or smoky environment, the unit should be periodically “blown free” of foreign dust and matter.
14. To reduce the risk of electric shock, do not remove the cover. There are no user serviceable parts inside. Refer all servicing to qualified service personnel. There are no user serviceable parts inside.
15. When moving the unit, disconnect input ports first, then remove the power cable; finally, disconnect the interconnecting cables to other devices.
16. Do not drive the inputs with a signal level greater than that required to drive equipment to full output.
17. The equipment power cord should be unplugged from the outlet when left unused for a long period of time.
18. Save the carton and packing material even if the equipment has arrived in good condition. Should you ever need to ship the unit, use only the original factory packing.
19. Service Information Equipment should be serviced by qualified service personnel when:
    A. The power supply cord or the plug has been damaged.
    B. Objects have fallen, or liquid has been spilled into the equipment.
    C. The equipment has been exposed to rain.
    D. The equipment does not appear to operate normally, or exhibits a marked change in performance.
    E. The equipment has been dropped, or the enclosure damaged.

THIS SAFETY INFORMATION IS OF A GENERAL NATURE AND MAY BE SUPERSEDED BY INSTRUCTIONS CONTAINED WITHIN THIS MANUAL.

SAFETY PRECAUTIONS

Please read all instructions before attempting to unpack, install or operate this equipment and before connecting the power supply. Please keep the following in mind as you unpack and install this equipment:

- Always follow basic safety precautions to reduce the risk of fire, electrical shock and injury to persons.
- To prevent fire or shock hazard, do not expose the unit to rain, moisture or install this product near water.
- Never spill liquid of any kind on or into this product.
- Never push an object of any kind into this product through any openings or empty slots in the unit, as you may damage parts inside the unit.
- Do not attach the power supply cabling to building surfaces.
- Use only the supplied power supply unit (PSU). Do not use the PSU if it is damaged.
- Do not allow anything to rest on the power cabling or allow any weight to be placed upon it or any person walk on it.
- To protect the unit from overheating, do not block any vents or openings in the unit housing that provide ventilation and allow for sufficient space for air to circulate around the unit.

DISCLAIMERS

The information in this manual has been carefully checked and is believed to be accurate. We assume no responsibility for any infringements of patents or other rights of third parties which may result from its use.

We assume no responsibility for any inaccuracies that may be contained in this document. We make no commitment to update or to keep current the information contained in this document.

We reserve the right to make improvements to this document and/or product at any time and without notice.

COPYRIGHT NOTICE

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or any of its part translated into any language or computer file, in any form or by any means — electronic, mechanical, magnetic, optical, chemical, manual, or otherwise — without the express written permission and consent.

© Copyright 2020. All Rights Reserved.
Version 1.5 MAY 2020

TRADEMARK ACKNOWLEDGMENTS

All products or service names mentioned in this document may be trademarks of the companies with which they are associated.

www.shinybowusa.com

122 Rose Ln. Suite 303 | Frisco, Texas 75036

sales@shinybowusa.com

TABLE OF CONTENTS

INTRODUCTION & CONTENTS 2
FEATURES & SPECIFICATIONS 3
FRONT & BACK PANELS 4
TRANSMISSION ANGLE OF DIFFERENT TYPE OF FIBER 5
DIAGRAM 6

INTRODUCTION

HDMI To Fiber Optic Extender

Thank you for purchasing the SB-6531T/SB-6531R HDMI To Fiber Optic Extender. You will find this unit easy to install and highly reliable but it is essential that you read this manual thoroughly before attempting to use Amplifier.

Compact 4K2K HDMI to fiber optic converter and extender for sending uncompressed HDMI signal up to 984ft (300M) over low cost fiber optic cable. Perfect for remote camera shoots, digital projection systems, HDTV streams to multiple locations and other equipment requiring HDMI to fiber conversion. This system utilizes simplified LC connectors and is powered via USB. The kit includes (2) USB power cables and (1) external USB power supply. The external power supply can be used to power either the Transmitter or the Receiver for source/display devices that do not have a USB port. The SB-6531KIT includes both the fiber Transmitter AND fiber Receiver.

PACKAGE CONTENTS

Check that you have the following components;

- SB-6531T HDMI to Fiber Transmitter
- SB-6531R Fiber to HDMI Receiver
- (2) 3 feet, USB 2.0 A Male to Micro 5pin Male power cables
- (1) 16 Inch, USB 2.0 A Male to Micro 5pin Male power cable
- 5VDC USB power supply
- Users Guide

FEATURES

- Extends HDMI signals up to 984ft (300M) over multimode fiber
- Ultra HD 4K2K & full HDTV video resolutions up to 720p/1080i/1080p@60Hz
- Fully uncompressed video & audio provides zero loss of quality
- Supports true DDC/EDID/HDCP transmission over fiber
- Video over (2) multimode fibers
- Miniature form factor for ease of use and installation
- Device power from USB port (500mA)
- Uses Fiber Optic Cable, LC/LC, OM1, OM2 or OM3, Multi-Mode, Duplex (50, 62.5/125 Type)

SPECIFICATIONS

- **Type of Extender:** Fiber Transmitter for HDMI signal over Optical Fiber Cable
- **Input Signals:** HDMI
- **Signal Support:** HDMI 1.4a HDMI format standard and HDCP compliant
- **Video Support:** 1920x1200 / 1080p@60Hz, up to 4K2K@30Hz
- **Audio Support:** Dolby TrueHD, Dolby Digital Plus, DTS, DTS-ES 6.1, DTSHD, DTS-HD-HRA, DTS-HD Master, (PCM-2CH)
- **Website Specifications:** Color space 444, 420, 400
- **Dynamic EDID:** Plug & Play, no need to learn
- **Fiber Connector:** Double LC Receptacle
- **Transfer Distance:** Multi Mode, up to 984ft (300M)
- **Operating Temperature:** 0°C to + 50°C
- **Storage Temperature:** -20°C to + 85°C
- **Humidity:** to 90% RH (non-condensing)
- **Safety Approvals:** CE
- **Dimension (WxDxH):** 3.15 x 0.79 x 0.35 in (80x20x9mm)
- **Weight:** 0.1 kg / 0.22 lb
- **Operation Voltage:** 5 DVC
- **Power Supply:** Power Input +5VDC, 0.85A (Universal Type 50/60Hz, 100~240VAC)

As product improvements are continuous, specifications are subject to change without notice.

FRONT & BACK PANEL - INPUTS/OUTPUTS

TRANSMITTER



1. **HDMI Input:** HDMI signal Input Fiber HDMI Source
2. **Fiber Out:** Optical Fiber out to SB-6531R
3. **USB:** DC 5V input

RECEIVER



1. **HDMI Output:** HDMI signal output to TV
2. **Fiber Input:** Optical Fiber Input from SB-6531T
3. **USB:** DC 5V input

TRANSMISSION ANGLE OF DIFFERENT TYPE OF FIBER

FIBER TYPE	FIBER SPECIFICATION	DISTANCE (METERS)	DISTANCE (FEET)
OM1	62.5/125μm	33	108
OM2	50/125/62.5μm	82	270
OM3	50/125μm	300	984

DIAGRAM


DVD
SB-6531T
HDMI To Fiber Optic
Transmitter
TX
OM3 Fiber
300M
RX
SB-6531R
Fiber Optic To HDMI
Receiver
TV

THIS PAGE IS INTENTIONALLY LEFT BLANK.

THIS PAGE IS INTENTIONALLY LEFT BLANK.

THIS PAGE IS INTENTIONALLY LEFT BLANK.

LIMITED WARRANTY

PLEASE READ THE FOLLOWING TERMS AND CONDITIONS CAREFULLY BEFORE USING THIS HARDWARE, COMPONENTS AND SOFTWARE PROVIDED BY, THROUGH OR UNDER SHINYBOWUSA, INC (COLLECTIVELY, THE "PRODUCT"). By using or installing the product, you unconditionally signify your agreement to these Terms and Conditions. If you do not agree to these Terms and Conditions, do not use the product and return the product to SHINYBOWUSA, Inc. at the return address set forth on the product's packing label at your expense. SHINYBOWUSA, Inc. may modify these Terms and Conditions at anytime, without notice to you.

RESTRICTIONS ON USE OF THE PRODUCT

It is your responsibility to read and understand the installation and operation instructions, both verbal and in writing, provided to you with respect to the product. You are authorized to use the product solely in connection with such instructions. Any use of the product not in accordance with such instructions shall void any warranty pertaining to the product. Any and all damages that may occur in the use of the product that is not strictly in accordance with such instructions shall be borne by you and you agree to indemnify and hold harmless SHINYBOWUSA, Inc. from and against any such damage.

The product is protected by certain intellectual property rights owned by or licensed to SHINYBOWUSA. Any intellectual property rights pertaining to the product are licensed to you by SHINYBOWUSA, Inc. and/or its affiliates, including any manufacturers or distributors of the product (collectively, "SHINYBOWUSA") for your personal use only, provided that you do not change or delete any proprietary notices that may be provided with respect to the product.

The product is sold to you and any use of any associated intellectual property is deemed to be licensed to you by SHINYBOWUSA for your personal use only. SHINYBOWUSA does not transfer either the title or the intellectual property rights to the product and SHINYBOWUSA retains full and complete title to the intellectual property rights therein. All trademarks and logos are owned by SHINYBOWUSA or its licensors and providers of the product, and you may not copy or use them in any manner without the prior written consent of SHINYBOWUSA, which consent may be withheld at the sole discretion of SHINYBOWUSA.

The functionality and usability of the product is controlled by SHINYBOWUSA, Inc. from its offices within the State of Texas, United States of America. SHINYBOWUSA makes no representation that materials pertaining to the product are appropriate or available for use in other locations other than the shipping address you provided with respect thereto. You are advised that the product may be subject to U.S. export controls.

DISCLAIMERS AND LIMITATION OF LIABILITY

SHINYBOWUSA may change or modify the product at any time, from time to time.

THE PRODUCT IS PROVIDED "AS IS" AND WITHOUT WARRANTIES OF ANY KIND EITHER EXPRESS OR IMPLIED. SHINYBOWUSA DOES NOT WARRANT OR MAKE ANY REPRESENTATIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE PRODUCT'S CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE.

SHINYBOWUSA has no duty or policy to update any information or statements pertaining to the product and, therefore, such information or statements should not be relied upon as being current as of the date you use the product. Moreover, any portion of the materials pertaining to the product may include technical inaccuracies or typographical errors. Changes may be made from time to time without notice with respect to the product.

TO THE FULLEST EXTENT PERMISSIBLE PURSUANT TO APPLICABLE LAW, SHINYBOWUSA DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. SHINYBOWUSA DOES NOT WARRANT THE ACCURACY, COMPLETENESS OR USEFULNESS OF ANY INFORMATION WITH RESPECT TO THE PRODUCT. SHINYBOWUSA DOES NOT WARRANT THAT THE FUNCTIONS PERTAINING TO THE PRODUCT WILL BE ERROR-FREE, THAT DEFECTS WITH RESPECT TO THE PRODUCT WILL BE CORRECTED, OR THAT THE MATERIALS PERTAINING THERETO ARE FREE OF DEFECTS OR OTHER HARMFUL COMPONENTS. SHINYBOWUSA WILL USE ITS REASONABLE EFFORTS TO CORRECT ANY DEFECTS IN THE PRODUCT UPON TIMELY WRITTEN NOTICE FROM YOU NOT TO EXCEED 10 BUSINESS DAYS AFTER RECEIPT BY YOU OF THE PRODUCT, BUT YOU (AND NOT SHINYBOWUSA) ASSUME THE ENTIRE COST OF ALL NECESSARY SERVICING, REPAIR AND CORRECTION THAT WAS CAUSED BY YOU UNLESS OTHERWISE AGREED TO IN A SEPARATE WRITING BY SHINYBOWUSA.

UNDER NO CIRCUMSTANCES, INCLUDING, BUT NOT LIMITED TO, NEGLIGENCE, SHALL SHINYBOWUSA BE LIABLE FOR ANY SPECIAL OR CONSEQUENTIAL DAMAGES THAT RESULT FROM THE USE OF, OR THE INABILITY TO USE THE PRODUCT IN ACCORDANCE WITH ITS SPECIFICATIONS, EVEN IF SHINYBOWUSA OR ITS REPRESENTATIVES HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL SHINYBOWUSA'S TOTAL LIABILITY TO YOU FROM ALL DAMAGES, LOSSES, AND CAUSES OF ACTION (WHETHER IN CONTRACT, OR OTHERWISE) EXCEED THE AMOUNT YOU PAID TO SHINYBOWUSA, IF ANY, FOR THE PRODUCT.

END OF DOCUMENT