
Telesteps®

ENGINEERED CLIMBING




www.telestepsworldwide.com



● Ladder Adjustment Instruction:

- Step 1: Measure the vertical distance from the floor to the ceiling. This ladder can be used in 8,9 and 10 ft. ceiling height applications.

- Step 2: The bottom 3 sections of the ladder can be adjusted manually for 8 ft 9 ft and 10 ft ceiling heights.Fig 2.





● Ladder Installation Instructions

- Once the loft/attic ladder frame bracket has been attached to the ceiling joist,attach the frame brace retainer belts around the tubes and secure to the door with 4 washers and 4 screws(screws not included)as shown in Fig 4.This will secure the loft ladder frame bracket to the door and prevent movement of the frame.



- Attach the Loft/Attic ladder frame bracket to the back of the opening to the joist with the provided screws as shown in Fig 5.
- Make sure to use a second ladder when installing the Attic/Loft ladder assembly to the ceiling joist and opening door. Do not stand on the Loft/Attic ladder until completely assembled. Fig. 6 and 7.






- The closed ladder height can easily be adjusted by moving the retainer hook bar to different hole positions on the 2 door frame braces. Fig. 8




- During the ladder frame assembly the retention spring can be adjusted so that it is not too tight. Fig 9.




● Opening the ladder


- Once the ladder frame assembly has been secured to the the ceiling joist and door, simply pull down on the door slowly with the pull down cord to bring the ladder down to use.Fig 10.

- The Attic/Loft ladder will be ready for use once the door has been fully opened.Fig 11.





- Open the Attic/Loft ladder by gripping the tubes with both hands and lifting it off the retainer hook and allowing it to open and descend to the floor. Fig 12.



- You will notice that there are windows on each side of the rungs/step of the ladder. Once these locking indicator windows turn from red to green when the ladder descends, that will indicate that the sections of the ladder are locked and the ladder is safe to use.Fig 13.




- The ladder should come to rest on the floor at a 75 degree angle when opened.Fig 14.



- If the Attic/Loft ladder feet do not touch the floor when opened there are 3 additional sections that can be opened manually for 8,9 and 10 ft. ceiling height applications. Fig. 15.



- Open the additional sections of the ladder by pressing the black buttons on either side of the rungs toward the center of the rungs to release the locking mechanisms for that section.



- Once the Attic/Loft ladder feet are firmly positioned against the floor at 75 degrees and all sections are locked by ensuring that the locking indicator windows on each side of the rungs/steps have turned from red to green,the ladder is safe to climb.Fig 17.



- Climb the Attic/Loft ladder by facing the front of the ladder. Grip the outside tubes of the ladder with your hands and climb the rungs one by one in succession. Fig 18.



- Do not climb the ladder from the back side.Fig 19




Closing the Ladder

- To close the Attic/Loft ladder you must first ensure that all of the manually opened bottom rungs are closed manually.Fig 20




- Once these rungs have been unlocked simply push up on the ladder with both hands firmly on the both tubes of the ladder until all sections of the ladder have retracted.Fig 21



- Once the ladder is fully closed, place the ladder retainer hook on the retainer bar to secure the ladder in position. Fig 22.



- Then close the ladder door to secure the door and Attic/Loft ladder in place. Fig 23.



- Please be careful when opening the Attic/Loft ladder door by pulling slowly and in a controlled manner to bring the ladder down. Do not pull too hard or too sharply to prevent personal injury.Fig 24.

LIMITED WARRANTY

TELESTEPS warrants this product to be free from defects in materials or workmanship for a period of one (1) year from original date of purchase. This warranty does not apply to any damage resuliting from abuse, normal wear and tear, unauthorized alteration,shipping or failure to use the product in accordance with instructions.

In the even of any defect, this product will be repaired or replaced, at TELESTEPS option without charge, The obligation to repair or replace this product,at TELESTEPS option,shall be TELESTEPS only obligation with respect to defects in this product.This product must be returned PREPAID.together with sales slip or other proof of purchase date.

Contact the Service Department, 9320 4th Ave. Seattle, WA 98108 PRIOR AUTHORIZATION FROM TELESTEPS IS REQUIRED FOR RETURN.

TELESTEPS WILL HAVE NO LIABILITY FOR ANY CONSEQUENTIAL, INCIDENTAL, OR SPECIAL DAMAGES ARISING OUT OF THE USE OF THE PRODUCT, ANY DEFECT IN THE PRODUCT OR OTHERWISE except to the extent that this limitation is precluded by applicable law.

THIS LIMITED WARRANTY,WHICH STATES THE FULL OBLIGATION OF TELESTEPS, GIVES YOU CERTAIN LEGAL RIGHTS.YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.TELESTEPS SPECIFICALLY EXCLUDES ALL IMPLIED WARRANTIES INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF FITNESS FOR PURPOSE AND MERCHANTABILITY.

www.telestepsworldwide.com